

operation manual

- Product data sheet (1-1) - Status 01-2019- V1.00

Item No. 22767 - LED Camping Lantern CT-CL Copper SOLAR

ØxH 12x23.5cm, warm white, dimmable

Product description:

Spend the evenings on the terrace or balcony with the cozy glow of a kerosene lamp - only without the risk of fire! This 23cm high LED camping lamp in a coppercolored metal housing hides an LED lamp with a wonderful light behind the frosted glass!

Technical details:

- ON / OFF rotary switch with dimming function
- max. 420 lumens, warm white LEDs 2700K
- On / off switch with dimmer
- Handle with hanging option
- Operation via solar cell and 1x 1865 battery 2000mAh
- ØxH 15x23cm







Safety instructions and important information!

In order to guarantee safety at all times and to use the full performance spectrum of the device, please read the safety instructions carefully and carefully!

The product must not be modified technically or mechanically, otherwise

The operating permit and conformity expire with immediate effect!! The nameplate / imprint must not be removed under any circumstances! Check the product for damage before each use. If there is any damage to the product, it must be dated

Be checked, repaired or replaced by a specialist company and disposed of in accordance with the applicable guidelines (see footer on page 1). Under no circumstances may a damaged or defective product continue to be used! Please make sure to secure all packaging material and accessories, especially small parts such as screws and foils, from children and animals. Suffocation hazard! The manufacturer assumes no liability for damage to property or personal injury in the event of noncompliance with the instructions or improper use, misuse or changes made to the product. The product must never be covered during operation! This product must never be operated, kept, put down or stored in the reach of children or animals. Keep these instructions in a safe place. If this product is passed on, the instructions and packaging must be included. Thanks! We reserve the right to make misprints or changes to packaging, the product or the instructions.

Notes on lighting and battery operation

Never look directly or unprotected into the light or the LEDs, the brightness can dazzle you and you risk injuries and possibly permanent damage to the eyes or the retina. Never point the lamp at people or animals! The product must never be covered during operation! Fire hazard! Open the battery cover and insert the batteries correctly. Unscrew the twist lock on the back with a magnet.

• When inserting the batteries, make sure that the polarity (±) is correct. • Please use only leak-proof, high-quality batteries / accumulators. • Always remove batteries / rechargeable batteries if they are not going to be used for a long time. • Store the product and batteries / rechargeable batteries only at 15-25 ° C in dry rooms. • Batteries / rechargeable batteries are not toys and must not be kept or used in the reach of children. Always pay attention to the batteries / rechargeable batteries, damaged or leaked batteries / rechargeable batteries can cause serious injuries - always use protective goggles and protective gloves.

Electronic products that are marked with the crossed-out garbage can do not belong in the household waste! You can hand these products in free of charge at the municipal collection points. Inquire here at your local authority, the responsible town hall or a local or municipal waste disposal company. Thanks very much. Used batteries should not be put in the household garbage. Consumers are legally obliged to bring batteries to a suitable collection point at the trade or municipality. Old batteries may contain pollutants or heavy metals that can damage the environment and health. The symbols under the label (garbage can) stand for:

Pb: battery contains lead, Cd: battery contains cadmium Hg: battery contains mercury. The environment and ChiliTec say thank you.